



Package inchlude

1. Outdoor Machine & 1. Indoor Machine set



ndoor Machine (Build-in rechargeable battery included)

Outdoor Machine (Build-in rechargeable battery included)



Charger & Cable



Detailed Manual& Quick Start Guide



Screws & Anchors



Indoor Machine

Power ON/ OFF

Long press for 3 seconds to ON/ OFF the device Short press to turn off ringtone Low power - Flashing the red light

TALK Key

eep pressing the TALK key to talk

Charging Stand

The indoor machine can keep working about 1-2 days nly, so we suggest that you keep the indoor machine on the charging stand after used

Note:

- 1. Every conversation must be: started by an outdoor machine
- 2. The indoor machine is turn off when you received it, so please press&hold ON/OFF button for 3 seconds to turn on it at first.



Outdoor Machine



Note:

- Outdoor machine will enter sleep mode in 25 seconds later if no action on it. So the rechargeable batteries for outdoor units can be used for 4-6 months after full charged
- 2. The outdoor machine only have 20% power when you received it. So please full charge it at first





Step 1: Visitor Click the CALL button to make a tone in indoor machine;



Step 2: Homeowner hear the tone, then waiting the tone stop or click ON/OFF button to stop the tene;



Step 3: After the tone stopped, homeowner press & hold TALk button to say"Hello, who is speaking, please?"



Step 4: The visitor hear the voice from homeowner, reply "i'm ,, open the door please";







1/3 Mile Range

Expand More Indoor or Outdoor Unit Special Design for Anti-interference



