

	Function options		Description	Application Notes
JP1		HWS	Open, Stop & Close	
		OP/CL	Open & Close only	
JP2	Auto Close	30 Sec	Gate auto close after remained open for 30secs	
		OFF	Select if function not required	
JP3	Open	ON	Open Revese enabled	If on, the movement of the gate is
	Reverse	OFF	Open Revese disabled	first reversed, then open
JP4	Light	Follow	Light status & motor movement in parallel	Light is on when motor is on, light is off when motor is stopped
		Delay	Light status is set to be off after a delay of 30 seconds	When gate is closed, light will be off after 30 sec
JP5	Soft Start	ON	Soft Start enabled	Firmware Run at 3speed
		OFF	No Soft Start function	Slow → Fast → Slow
JP6	HI Speed	ON	Hi Speed Over Load ON	
	Over Load	OFF	NO Hi Speed Over Load	