



## check modem/router gateway ip

8.



## Select Advanced tap

9.



## change the ip address type to Static and submit to save

10.



## set the ip address, netmask and gateway (refer to step 8) and submit to save change

11.



## reboot to complete the configuration

12.

