

NEW

# K1 Single Door Standalone

## Access Control

Mode Can Setting ⇨ Card or PIN (3 2 #)

Default Master Code ⇨ 123456

User ID ⇨ 1 - 2000

User PIN ⇨ 0000 - 9999 - (4 Digits Only)

### To Add User PIN With Specific ID

⇨ \* 123456 # ⇨ 1 ⇨ User ID # ⇨ PIN # ⇨ \* \* Done.

### To Delete User PIN By ID

⇨ \* 123456 # ⇨ 2 ⇨ User ID # ⇨ \* \*

↓  
If You Delete User ID the  
PIN Also Will Be Deleted

To Change User PIN ⇨ This Step Must Be Done Out of Programming Mode

⇨ \* User ID # ⇨ Old PIN # ⇨ New PIN # ⇨ New PIN #.

### To Add Card With Specific ID

⇨ \* 123456 # ⇨ 1 ⇨ User ID # ⇨ Flash Card ⇨ \* \*

### To Delete User Card

⇨ \* 123456 # ⇨ 2 ⇨ Flash Card ⇨ # ⇨ \*

### To Delete User Card By ID

⇨ \* 123456 # ⇨ 2 ⇨ User ID # ⇨ # ⇨ \* \*

↓  
If You Delete the User ID the  
Card Also Will Be Deleted



Scanner Pro

